

tuforte[®] sr



TECHNICAL DATA SHEET

TOPECA, Lda
Rua do Mosqueiro
2490-115 Cercal – Ourém
PORTUGAL

Tel.: 00 351 – 249 580 070
Fax.: 00 351 – 249 580 079

TOPECA
FÁBRICA DE PRODUTOS PARA CONSTRUÇÃO

geral@topeca.pt
www.topeca.pt

tuforte

sr

levelling and regularization

rapid drying bitumen for interiors, fills cracks and holes



use

Bitumen for the preparation and repair of surfaces.
 Fills cracks, nail or screw plug holes, removes surface damage and levels painted and unpainted walls.
 Can be used with fibre glass in unstable joints and clacks.
 Allows screw plugs and nails to be used on walls without the occurrence of cracking.
 Fills cracks and holes easily due to its fine composition.

surface

- Plaster;
- Stucco;
- Brick;
- Cement;
- Render;
- Painted surfaces in good condition;
- Plasterboard



tuforte sr

rapid drying bitumen for interiors, fills cracks and holes

levelling and regularization

recommendations

Protect metal fittings with an anticorrosive primer before applying Tuforte sr.
Do not add more water or remix the bitumen after curing has started.

composition and characteristics

Composition:

Special plasters, selected fillers and specific additives.

Characteristics:

Time to use the mixture: 35 minutes.

Setting time: 40 minutes.

Bulk density: 0.95 g/cm³.

Timeout to coat: 3-4 hours

(depending on the support, the layer thickness and atmospheric conditions).

Note: Results obtained in the laboratory (T = 20 ° C) may vary depending on the application temperature.

colour

White.

consumption

2 kg/litre.

available in

Pack of 1 kg.

Box with 20 packs.

storage

1 year after date of manufacture in unopened package and in a damp free environment.



tuforte sr

rapid drying bitumen for interiors, fills cracks and holes

levelling and regularization

preparation of surface

Clean the area where Tuforte sr is to be applied removing any dust, loose chippings and grease.

With deep holes or cracks, the cavity must be suitable prepared and cleaned in order for the bitumen to attach easily.



application

Mix Tuforte sr (1Kg) with approximately 500 ml of water, stirring well until an even and lump free paste is obtained.



Crack: This is the easiest problem to resolve.

Fill cracks with bitumen using a spatula. Press firmly into crack.



Deep cracks and holes: Filling the crack may not resolve the problem as it may reopen. Therefore, Glass fibre webbing must be used.

Marks and surface damage: Follow same procedure as for deep cracks.

Ceilings displaying cracks are repaired in the same way as walls.

When the ceiling in question is located directly beneath a wooden floor, any cracking will almost certainly reappear. A fine mesh fibre glass webbing should also be used in these cases.

Repaired areas can be touched up as many times as required.



When dry, the area can be improved by light sanding.

