

TECHNICAL DATA SHEET

TOPECA, Lda Rua do Mosqueiro 2490-115 Cercal – Ourém PORTUGAL

Tel.: 00 351 – 249 580 070 Fax.: 00 351 – 249 580 079

> geral@topeca.pt www.topeca.pt



tuforte sintético

adjustment of walls and ceiling of interior





levelling and regularization

 $\boldsymbol{\cdot}$ extra fine finish, perfect and uniform

Use

Mass finishing to stabilize and fine finishes on walls and ceilings, allowing for a surface ready to receive the final decoration.

Allows settling cracks, holes, ripples and other imperfections.

Tuforte Sintético allows an extra fine finish, perfect and uniform.

Tuforte Sintético is easy to apply. Glides smoothly, with the advantage for easy sanding.

Tuforte Sintético has a large filling capacity and outstanding adhesion to most building materials.

surface

- Concrete;
- Render;
- Plaster;

• Paint (in good condition, adherent and resistant);

• Primary / insulating paint;

• Mortar (Tuforte FT, Tuforte Barramento, Tuforte Estanhar) and plaster board.



tuforte sintético

adjustment of walls and ceiling of interior

recommendations

Admissible covering: painting and decorative paper, corticite.

Do not put in surfaces with moisture problems by capillarity.

Product ready for use, it is not advisable to dilute the product.

If you want to cover with paint should wait about 48 hours prior to sanding with fine sandpaper on support, thus ensuring the total drying Tuforte Sintético. Then clean all the support before applying the primary regulator Fund and finally applying paint.

levelling and regularization

composition and characteristics

Composition:

Product based on acrylic resins and selected load.

Characteristics:

Dry to touch: 2 to 4 hours. Drying Total: 24 to 48 hours Waiting time to be able to repaint: 48 hours. Apply at temperatures of +5 ° C to +30 ° C.

Note: Results obtained in Laboratory conditions may vary depending on application conditions.

colour

White

consumption

0.7-1 Kg/m²

avalable in

Bucket of 25kg

storage

1 year after working in original container and protected from moisture.



tuforte sintético

adjustment of walls and ceiling of interior

preparation of surface

Substrates must be flat, stable, clean, dust, oil fumes or parting compounds.

All projections shall be smoothed and cavities or damage of any kind exceeding 5 mm, must first be met. Nails and other existing objects should be removed. Remove all loose parts.

application

Mix the Synthetic Tuforte in order to homogenize the product before application.

Apply with the help of a spatula, trowel or putty knife metal.

After drying, improve the surface with fine sandpaper. Past 2-3 days may be covered with ink or paper. Wash tools with water.



levelling and regularization





