juntaemcor dry

Dry mortar for joints





- prevents the appearance of grass
- promotes uniform color to the pavement

use

Mortar to fill the lace joints of pavé concrete blocks, cement artifacts, applied to pavements (new or rehabilitation).

surface

Concrete blocks for floors.







juntaemcor dr

Dry mortar for joints

recommendations

Filling the joints is done with the Juntaemcor Dry, do not mix the product with water. Do not apply the Juntaemcor Dry on rainy days or with high probability of rain in the days following the application.

Use the Juntaemcor Dry in the color that most closely resembles the color of the floor elements.

composition and characteristics

Composition: Specific cements, aggregates and adjuvants.

Characteristics:

Time to transit (pedestrian traffic): 24 hours;

Definitive opening to circulation: 6 days at 20°C.

Pulp density: 1500 Kg/m³

Note: These results were obtained in our laboratory, under standard conditions, may vary with the reduction or increase of temperature and the type of support.

colour

White, Gray, Black, Red, Yellow and Green.

consumption

As an indication for pieces with 22x11x6cm and 0,7cm of joint width- 9 kg / m^2 .

For other sizes of pieces, consult the consumption chart at www.topeca.pt.

available in

25 kg sacks.

storage

1 year after date of manufacture in unopened package and in a damp free environment.





Juntaemcor dry

Dry mortar for joints

preparation of surface

Before applying the Juntaemcor Dry you should compact the floor elements to level the floor; The supports must be perfectly dry.

In the rehabilitation of floors, it is necessary to pre-wash with water under pressure, in order to remove any disaggregated material existing in the joint.

It is recommended to exist at least 3 cm deep, to be filled with the Juntaemcor Dry.



application

After seating the floor elements, fill all joints between the tiles with Juntaemcor Dry. Spread Juntaemcor Dry over the pavement surface using brooms.

Sweep in all directions to fill all spaces between floor elements. The excess Juntaemcor Dry should be swept off the pavement so that the pavement is completely clean.



Lightly moisten by spraying, without resorting to pressure. On the next day, return to moisten with water, by spraying, without resorting to pressure.

Keep the floor moist for 5 days, avoiding traffic on the pavement.





